



---

# SAFARI ARMAX SNORKEL BRACKET

---

TLR641201



SUITED TO:  
**TOYOTA LANDCRUISER  
70 SERIES**



## PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 10 minutes.



Basic spanner, socket set, flat & Phillips head screwdriver, pliers, scissors

FITTING KIT	
QUANTITY	PART
1	TLR641201
2	M8 x 30 mm SS Button Head Socket
2	M8 SS Spring Washer
2	M8 SS Flat Washer



### NOTE:

This Safari Armax Snorkel Bracket to suit the Safari Armax is designed to mount to the top right-hand side A-pillar of the Toyota Landcruiser 70 series range.



## FITTING INSTRUCTIONS

1. Remove the two factory bolts and rubber isolator from upper OME Toyota bracket and discard the bolts. Retain the rubber.
2. Fit the new TLR Products bracket to the A pillar using supplied M8 bolts and the rubber from the factory mount fit bracket. **Photo 1**
3. Place snorkel against the guard and fit the factory bolt. This will make sure perfect alignment with the new bracket. **Photo 2**
4. Reuse the Safari Snorkel hose clamp, pass it through the slot in the bracket and tighten.
5. Finish bolting the snorkel body to the guard.



TLR Products  
65 Northville Drive  
Barnsley NSW 2278



hello@tlrproducts.com.au  
www.tlrproducts.com.au



instagram.com/tlrproducts  
facebook.com/tlrproducts