



---

# AERIAL BRACKET ROLLER SHUTTER CHANNEL

---

TLR744003



SUITED TO:

**FORD RANGER RA SERIES (NEXT GEN)**  
**FORD RANGER PX SERIES**  
**TOYOTA HILUX N80**



## PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 30 minutes.



Socket set  
Spanners

### FITTING KIT

QTY	PART
1	TLR744003-1 – Aerial Bracket
2	TLR744003-2 – M6 Channel Stud
2	M6 Nyloc Nut – Stainless Steel
2	M6 x 12 Flat Washer – Stainless Steel



#### NOTE:

This Aerial Bracket is designed to mount to the mounting channel found along both side of the OEM roller shutter mount.



## FITTING INSTRUCTIONS

1. Refer to Photo 1. Slide supplied channel studs into mounting channel.
2. Refer to Photo 2. Place TLR Products Aerial bracket over channel studs and install in place using hardware supplied.



Photo 1



Photo 2



[instagram.com/tlrproducts](https://www.instagram.com/tlrproducts)  
[facebook.com/tlrproducts](https://www.facebook.com/tlrproducts)



[hello@tlrproducts.com.au](mailto:hello@tlrproducts.com.au)  
[www.tlrproducts.com.au](http://www.tlrproducts.com.au)



TLR Products  
65 Northville Drive  
Barnsley NSW 2278