



---

# QUADLOCK®/RAM® PHONE MOUNTING BASE

---

TLR742108



SUITED TO:

**TOYOTA LANDCRUISER 70 SERIES  
DRIVER SIDE GRAB HANDLE**



## PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 15 minutes.



Screwdriver, Torx Socket Set, Plastic trim removal tool

### FITTING KIT

QUANTITY	PART
1	TLR741208-1 – Mounting Bracket
4	M5 x 16 SS Countersunk Phillips Head
4	M5 x 16 SS Pan Phillips Head
4	M5 SS Nyloc Nut

### NOTE:

This Mount is designed to suit all 70 series variants from 2007-on and locates on the driver's side grab handle.





## FITTING INSTRUCTIONS

1. Install the chosen phone mount components using the hardware supplied with both the phone mount components and the TLR Products fitting kit. **See photos 1 & 2.**
2. Remove the right-hand side A pillar grab handle by carefully removing the two mounting bolt covers and M6 Torx bolts. **Photo 3.**
3. Position the phone mount assembly over the two grab handle mounting bolt locations. Install the grab handle and M6 mounting bolts, ensure correct alignment and securely tighten the bolts. **Photo 4.**
4. Adjust phone mount pivot to the desired position to complete the installation.



hello@tlrproducts.com.au  
www.tlrproducts.com.au



instagram.com/tlrproducts  
facebook.com/tlrproducts