



QUADLOCK®/RAM® PHONE MOUNTING BASE

TLR744808



SUITED TO:

**MAZDA BT50 TF SERIES / ISUZU DMAX RG
SERIES / ISUZU MUX RJ SERIES
DRIVERS SIDE GRAB HANDLE**



PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 15 minutes.



Screwdriver, Socket Set, Plastic trim removal tool

FITTING KIT

QUANTITY	PART
1	TLR744808-1 Mounting Bracket
4	M5 x 16 SS Countersunk Phillips Head
4	M5 x 16 SS Pan Phillips Head
4	M5 SS Nyloc Nut

NOTE:

This Mount is designed to suit Mazda BT50 TF series / Isuzu Dmax RG series / Isuzu MUX and locates on the driver's side grab handle.





FITTING INSTRUCTIONS

1. Install the chosen phone mount components using the hardware supplied with both the phone mount components and the TLR Products fitting kit. **See photos 1 & 2.**
2. Remove the right-hand side A-pillar grab handle by carefully opening the mounting bolt covers and removing the mounting bolts. **Photo 3.**
3. Position the phone mount assembly over the two grab handle mounting bolt locations. Install the grab handle and mounting bolts, ensure correct alignment and securely tighten the bolts. Close the mounting bolt covers. **Photo 4.**
4. Adjust phone mount pivot to the desired position to complete the installation.



hello@tlrproducts.com.au
www.tlrproducts.com.au



instagram.com/tlrproducts
facebook.com/tlrproducts