



HD RECOVERY BOARD MOUNT

TLR940009



SUITED TO:

**ARB BASE RACK NORTH – SOUTH
FIXED PINS**



PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 15 minutes.



Socket Set
Screwdriver
Allen Keys

FITTING KIT	
QUANTITY	PART
2	TLR940009-4 Main Bracket Assembly
4	TLR940009-2 Clamp Bracket
4	M6 x 16 mm Button Head Socket Screw SS
4	M6 Nyloc Nut SS
8	M6 x 12.5 mm Flat Washer SS

NOTE:

This TLR Products Bracket set is designed to mount in a North-South orientation on the ARB Base Rack.

Suitable for TRED Pro/HD/GT, as well as MaxTrax Extreme/MKII/Lite.





FITTING INSTRUCTIONS

1. Install mounting pins to the TLR940009-1 Main Brackets using the hardware supplied with the pins.

NOTE: TRED pins will require the stepped washers to be used.

Photo 1.

2. Position the main brackets on the Base Rack in the desired location and install two TLR940009-2 Clamp Brackets to the underside of each Main Bracket using the supplied M6 hardware and securely tighten.

Photo 2. NOTE: Brackets must be positioned with the tapered sides facing each other for correct spacing.

3. Install recovery boards and lock pins to complete the installation.

Photo 3.



hello@tlrproducts.com.au
www.tlrproducts.com.au



instagram.com/tlrproducts
facebook.com/tlrproducts