



AERIAL BRACKET RIGHT-HAND SIDE BONNET

TLR741415



SUITED TO:

TOYOTA HILUX N90 SERIES



PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 15 minutes.



Spanner Socket Set

FITTING KIT	
QUANTITY	PART
1	TLR741415-1 Mounting Bracket
2	M8 x 25 mm Hex Head Bolt ZP
2	M8 Spring Washers ZP
2	M8 x 18 x 1.9 mm Flat Washer ZP
2	Cable Tie 150 mm

Note:

If installing Ditch Lights it is recommended to use the TLR Products Aerial Bracket Adapter Washers (TLR740001).





FITTING INSTRUCTIONS

1. We recommend applying masking tape along the rear edge of the bonnet to protect against damage during installation.
Photo 1.
2. Remove the two RH bonnet hinge mounting bolts.
NOTE: Ensure to hold the bonnet securely once the bolts are removed. We recommend the assistance of a second person.
Photo 2.
3. Place the TLR Products bracket over the bonnet hinge and install the supplied M8 Bolts, Spring and Flat Washers.
NOTE: Ensure adequate clearance around the bonnet before securing into place. **Photo 3.**
4. Check Clearance around plastic trim panel. Adjust the bracket inward to provide clearance if necessary.
5. Install the Aerial or Light of choice to finalise installation.



PHOTO 1



PHOTO 2



PHOTO 3



hello@tlrproducts.com.au
www.tlrproducts.com.au



instagram.com/tlrproducts
facebook.com/tlrproducts