



AERIAL BRACKET RIGHT-HAND SIDE BONNET

TLR741502



SUITED TO:

TOYOTA LANDCRUISER 200 SERIES



PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 15 minutes.



Spanner Socket Set

FITTING KIT	
QUANTITY	PART
1	TLR741502-1 – Mounting Bracket
1	TLR740004-2 – Wedge washer (14.5mm)
1	TLR740004-3 – Wedge washer (16.5mm)
2	Cable Tie 150 mm

NOTE:

This Aerial Bracket is designed to mount to the Right-hand side rear section of the bonnet.

Ditch Lights can be mounted to this bracket using the TLR740001 Adapter Washer set. (Available separately)





FITTING INSTRUCTIONS

1. It is recommended to place Masking Tape along the rear edge of the bonnet to protect against any damage during installation.
2. Remove the two bonnet mounting bolts from the hinge **Photo 1**, position the Aerial Mounting Bracket over the bonnet mounting holes and refit bonnet mounting bolts.
NOTE: It is recommended to have an assistant support the bonnet during the installation.
3. Once you have installed the bracket, ensure correct bonnet alignment and clearance **See Photo 2**.
4. Fit the Aerial or Light of choice to the Mounting Bracket and route the cable down the outside edge of the bracket and secure using the cable ties provided to prevent pinching. *NOTE: some vehicles can be angled nose down, we have supplied a correction washer to help compensate for alignment.*
5. Remove Masking Tape and confirm all hardware is secure to complete installation.



hello@tlrproducts.com.au
www.tlrproducts.com.au



instagram.com/tlrproducts
facebook.com/tlrproducts