



DEVICE MOUNT

TLR742504



SUITED TO:

TOYOTA LANDCRUISER 300 SERIES



PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 15 minutes.



Socket Set
Screwdriver
Trim Removal Tool

FITTING KIT	
QUANTITY	PART
1	TLR742504-1 – Mounting Bracket
1	TLR742504-2 – Plastic Insert
4	M5 x 16 SS Countersunk Phillips head
4	M5 x 16 SS Pan Phillips Head
4	M5 SS Nyloc Nut
1	M6 x 40 Button Head Socket Screw (BLACK)
1	M6 x 16 x 1.4 Flat Washer Zinc Black Passivate

NOTE:
This Mount is designed to suit the Right-Hand side grab handle of the Toyota Landcruiser 300 Series.
The mount features an AMPS hole pattern to accommodate both Quadlock and RAM Mounts components.





FITTING INSTRUCTIONS

1. Remove the small plastic trim piece from the lower section of the grab handle. **See photo 1.**
2. Remove the OE mounting bolt. **See Photo 2.**
3. Place the TLR Products mounting bracket, align the plastic insert spacer over the top and install the supplied M6 x 40 mm bolt and washer to fix the mount into place. **See Photo 3.**
NOTE: ensure the plastic insert is aligned correctly and not binding on installation.
4. Install the components of choice to the TLR Products mounting bracket using the hardware supplied. **See photo 4 and 5 for examples.**
5. Adjust device mount to suitable position.



[instagram.com/tlrproducts](https://www.instagram.com/tlrproducts)
[facebook.com/tlrproducts](https://www.facebook.com/tlrproducts)



hello@tlrproducts.com.au
www.tlrproducts.com.au